


Surface installation - Backplate ZVP-BPLA1/2/3 – ZVP-BP2W2H– ZVP-BP2W3H – ZVP-BP3W3H


GetFace IP

Assembly instructions


BACKPLATE ASSEMBLY (WALL)




BACKPLATE ASSEMBLY (GLASS)



BACKPLATE MODELS AND DIMENSIONS





© Zennio Avance y Tecnología S.L.